

***Weather Resistant Container
INST-568 Addendum to INST-150
Effective: 2/99
Expires: 2/09***

Installation, Operating & Maintenance Instructions

A. Mounting Location

Mount weather resistant container to a minimum 2" diameter pipe or structural member with the 4" eyebolt and provided hardware.

Height of eyebolt must be approximately 7 ft. above standing level. Anchorage point must support 1800 lb. in the direction of pull.

A smooth surface, such as a guardrail, should be used to act as a cable guide during escape. If guardrail or equal is not used as a cable guide, box will be damaged by the pressure of the descent cable. The surface must be very smooth, and the cable must be carefully inspected after each use. (See illustration.)

B. Specifications

- ABS plastic box 34-3/8" high x 13-5/8" deep x 18-3/8" wide.
- Synthetic rubber bulb seal gasket on door. Latch pulls door into synthetic rubber door gasket to form airtight seal.
- Hinges are integrally molded parts of door and frame for high strength and durability.
- Window 13-1/2" x 4", polycarbonate.
- Corrosion resistant handle.
- Aluminum bar 34-3/8" x 1/4" x 2" vertically attached at rear of box. Bar is permanently mounted on box with stainless steel bolts, sealed with silicone caulk.
- Stainless steel eyebolt 3/4" x 4"

C. Warning

Read and understand INST-150, Escaperite Instructions before using this product.

*One Sellstrom Drive
Palatine, IL 60067
847-358-2000 □ 1-800-323-7402
Fax 847-358-8564
INST-568*

