


Instruction: #INST-LS
 Sellstrom/RTC Product:
 Lany'd Sto™
 Effective: 6/2001
 Expires: 6/2011
 Page 1 of 1

Sellstrom/RTC® Lany'd Sto™

Installation, Operation & Maintenance Instructions

SM/RTC Lany'd Sto™



To the Equipment User:
 You must read and fully understand or have the following instructions explained to you before using this equipment. Failure to do so could result in serious or fatal injury.

WARNINGS



To the receiver, contractor, store manager, safety director, supervisor, buyer, and anyone other than the ultimate equipment users:

These instructions are not to be removed except by the user of this equipment. Current instructions always must be available to any potential user.

Note: Because of continual developments in the application and use of SM/RTC equipment, and because of our desire to best serve your interests, these instructions are invalid 10 years after their effective date. If these instructions are out of date, call SM/RTC Customer Service and request current instructions.

If you have any questions or need additional explanation or clarification about the use of any SM/RTC equipment, call SM/RTC Customer Service at 800-323-7402 (U.S. and Canada) or 847-358-2000 in Illinois or outside the Continental United States.

You must read and fully understand or have the following instructions explained to you before using this equipment. Failure to do so could result in serious or fatal injury.

Atencion: Si usted no puede leer el ingles o si usted no comprende estas instrucciones, favor de consultar su director de seguridad o su supervisor.

Attention: Si vous ne pouvez pas lire l'anglais ou si vous ne comprenez pas les instructions, consultez votre directeur de securite ou votre superviseur.

Achtung: Wenn Sie nicht Englisch lesen können und diese Anweisungen nicht verstehen, dann fragen Sie bitte Ihren Sicherheitsdirektor oder Ihren Aufseher.

Attenzione: Se non leggere l'inglese o non capite queste istruzioni, per favore rivolgete Vi al Vostro Direttore, responsabile della "Sicurezza sul Lavoro" o al Vostro diretto superiore.

You assume complete liability if you fail to follow these instructions and are injured. Use this equipment only as instructed.

Warning



No other applications or methods of use are allowed without prior written approval.

1.0 Approved Application

The Lany'd Sto™ provides a convenient way to store the end of a fall protection lanyard when it is not in use.

The Lany'd Sto' is a fall protection accessory. It does not provide fall protection. Do not use the Lany'd Sto' as an attachment point for fall protection equipment.

2.0 Installation and Attachment

Read and understand the harness and lanyard instructions provided by the manufacturer before using this product.

Connect the lanyard snaphook to the loop on the Lany'd Sto'.

Attach the Lany'd Sto' to the harness with the snaps provided, over the shoulder strap as shown.

3.0 Inspection

Inspect the Lany'd Sto' before each use for cuts, tears, burns, holes, or any other damage. Remove the Lany'd Sto' and inspect the harness and lanyard as instructed in the instructions provided by the manufacturer before each use.

Warning



If damage is found or you have questions or any doubts about the equipment's condition, do not use the equipment. Tag the system "DO NOT USE" and contact SM/RTC Customer Service for advice.

4.0 Maintenance

If the Lany'd Sto' becomes heavily soiled, it may be laundered with soap and water in any standard washer/dryer.

Store in a cool, dry place.

Sellstrom Manufacturing Co.
 One Sellstrom Drive
 Palatine, IL 60067
 Phone 800.323.7402
 Fax 847.358.8564
 www.fallprotection.com

© 2001 Sellstrom Manufacturing Co., All Rights Reserved

sellstrom / RTC®

INST-LS Printed in the U.S.A. Page 1 of 1